



KEY

Master Mon	Phones Out Sel [UTILITY], SYSTEM GLOBAL PRM
Aux Tr Cue	Effects Loop Return Select BUS [MODE]
Aux + Tr Cue	EFFECT RTN [LEVEL]
IN1 IN2 IN3 IN4	Channel Input [INPUT]
Mute Input	Channel Source SELECT [MODE] [SELECT]
Track	
IN1/2 IN3/4	Channel Input [INPUT]
Pre EQ Pre Pst	Aux Source [AUL LEVEL] CURSOR [V][V]

Pre Pst	Effects Source [EFFECT LEVEL] CURSOR[V][V]	Aux Level A Aux Level B	Aux Send Level [AUX LEVEL] (A) CURSOR [V] (B)	Mute Rec Play	Rec/Play Select [TRACK STATUS]	Mix Input (1)	External Mix EZ ROUTE - MIX DOWN	Track Cue Balance L R	Track Cue Balance [SHIFT] [CD] [V]
Ch L Pan R	Channel Pan [PAN]	Send Level	Effect Send Level [EFFECT LEVEL]	Master Tr Cue	Metronome Out Select [UTILITY], METRONOME	Off AB AB + CD CD	Effects Loop Return Select BUS [MODE] [SHIFT] EFFECT RTN [LEVEL]	Master Master + Tr Cue	Output Select [MONITOR SEL]
EFX L Pan R	Effect Send Pan [EFFECT LEVEL] CURSOR [V]	Master Tr Cue	Master Out Sel [UTILITY], SYSTEM GLOBAL PRM	AB CD	Record Bus Select BUS [MODE][BUS]	Track Cue Pan L R	Track Cue Pan [SHIFT] [CD] [V]	Tr Cue Rec Bus Aux Bus	

Version display: Press [Monitor Sel] and [Solo] during power up